

# SWDR SUMMARY SPREADSHEETS USER GUIDE

August 2017

California Department of Transportation Division of Design Office of Storm Water Management 1120 N Street Sacramento, California

# **TABLE OF CONTENTS**

1.	INTRODUCTION	4
1.1. 1.2. 1.3. 1.4.	OVERVIEW AUDIENCE DEVELOPMENT DATA ENTRY	4 4
2.	RESPONSIBILITIES	
2.1.	PROJECT ENGINEER & LANDSCAPE ARCHITECT	
3.	SWDR SPREADSHEET	7
3.1. 3.2.	WHERE TO FIND THE DATA IN THE SWDR COLUMN FIELD TYPES  3.2.1. Automatically Filled in 3.2.2. Date 3.2.3. Pull Down Menu 3.2.4. Number 3.2.5. No Restriction	
4.	TMT SPREADSHEET	
4.1. 4.2. 4.3.	COLUMN FIELD TYPES  4.1.1. Automatically Filled in  4.1.2. Pull Down Menu  4.1.3. Number  4.1.4. No Restriction  4.1.5. Currency  BMP TYPE PULL DOWN MENU  EXAMPLE TEXT FOR BMP SIZE AND LOCATION	
5.	REFERENCES	24

# **TABLE OF CONTENTS**

LIST OF	TABLES	
	AUTOMATICALLY FILLED IN FIELDS	
	2 DATE FIELDS	
	3 PULL DOWN MENU FIELDS	
_	5 NO RESTRICTION FIELDS	
	1 AUTOMATICALLY FILLED IN FIELDS	
	2 PULL DOWN MENU FIELDS	
	4 No RESTRICTION FIELDS	
TABLE 4-5	5 CURRENCY FIELD	21
	5 BMP TYPE PULL DOWN MENU 7 EXAMPLE TEXT FOR BMP SIZE AND LOCATION	
LIST OF	FIGURES	
	1 SWDR SPREADSHEET	
	2 SHORT FORM COVER SHEET	
	4 OVERALL PROJECT TREATMENT SUMMARY TABLE	
FIGURE 4-1	1 TMT Spreadsheet	16
LIST OF	ACRONYMS	
ac	Acres	
ATA	Additional Treated Area	
BMP	Best Management Practice	
CDA	Contributing Drainage Area	
Comp	Completed	
Const	Construction	
CT	Caltrans	
CU	Compliance Unit	
DEA	Division of Environmental Analysis	
DPPIA	Design Pollution Prevention Infiltration Area	
DSA	Disturbed Soil Area	
EA	Expenditure Authorization	
EFIS	Enterprise Resource Planning Financial Infra-Structure	
EPA	Environmental Protection Agency	
Est	Estimated	
EW	Erosivity Waiver	
FAC	Maintenance Facility	
GSRD	Gross Solid Removal Device	
HSA	hydrologic sub area	
IMMS	Integrated Maintenance Management System	
LA	Landscape Architect	

# **TABLE OF CONTENTS**

MCTT Multi-Chamber Treatment Train

MedFilter Media Filter

MWELO Model Water Efficient Landscape Ordinance

NNI Net New Impervious

NPDES National Pollutant Discharge Elimination System

OHSD Office of Hydraulics and Stormwater Design PA/ED Project Approval/Environmental Document

PCTA Post Construction Treatment Area

PE Project Engineer

PID Project Information Document

PM Post Mile

PPDG Project Planning and Design Guide PS&E Plans, Specifications & Estimate

RWB Regional Water Board
RSA Rapid Stream Assessment
RIS Replaced Impervious Surface

RL Risk Level
R/W Right of Way
SA Stabilized Area
SW Stormwater

SWDR Storm Water Data Report

SWMP Storm Water Management Plan TMDL Total Maximum Daily Load

TMT Tracking Maintenance Treatment

TST Traction Sand Traps

Var Various

WPCP Water Pollution Control Plan

WQAR Water Quality Assessment Report

WQF Water Quality Flow

WQPT Water Quality Planning Tool

WQV Water Quality Volume

# 1. INTRODUCTION

#### 1.1. OVERVIEW

This document contains additional guidance on the SWDR Summary Spreadsheets process to enhance Section 6.6 of the latest PPDG. Use this Guide for projects with a Project Initiation Document (PID) signed on or after July 1, 2013. This guide is structured to assist new and experienced data input people.

This guide is intended to assist the PE in understanding why the spreadsheets are necessary, what, when, where, who and why data is stored in the spreadsheets, where to obtain the data in the SWDR, and how to properly place the data in the spreadsheets.

#### 1.2. AUDIENCE

The intended audience of this Guide is Caltrans District Stormwater Coordinators, Project Engineers (PE), Landscape Architects (LA), and Maintenance Representatives that sign the cover sheet of the Stormwater Data Report (SWDR).

It is the responsibility of the Maintenance Representative to ultimately determine the final description that meets their needs and determine names for Maintenance Facilities. Refer to the Column labeled *BMP Specific Comments* on the TMT Spreadsheet in Table 4-4 for more information.

#### 1.3. DEVELOPMENT

The SWDR Summary Spreadsheets were developed for several reasons:

- Caltrans management has tasked the Office of Hydraulics and Stormwater Design (OHSD) to track the SWDR information and the number of treatment BMPs as part of design compliance monitoring in accordance with the Departments NPDES/SWMP requirements.
- 2. Division of Maintenance must track specific treatment BMP information in accordance with the NPDES/SWMP requirements and to meet future operation and maintenance needs. OHSD agreed to track this information for Maintenance through the planning and design phases of a project. The specific information tracked:
  - a. Name and location of BMP (including latitude, longitude, county, route and post mile);
  - b. Watershed, Regional Water Board, and Caltrans District where located;
  - c. Size and capacity; and
  - d. Treatment BMP type
- 3. Some of the fields tracked in these spreadsheets may be used for Program Evaluation (PPDG Section 2.2).

4. Some of the fields tracked are agreements between OHSD and DEA (i.e., Basis of BMP Requirement (non 402), additional Maintenance needs, and BMP Capital Cost).

This information was previously tracked through the SWDR Summary Spreadsheets data uploaded to OHSDs database tracking tool. DEA has agreed to track this information using the Stormwater Portal based on the Departments 2012 NPDES Permit. OHSDs tracking tool will no longer be supported.

OHSD collaborated with DEA and the Division of Maintenance on the data, format, and process to upload the SWDR Summary Spreadsheets (based on Caltrans 2012 NPDES Permit) into the Stormwater Portal. The Stormwater Portal has several automated features to enhance entering data that the SWDR Summary Spreadsheets don't.

The SWDR Summary Spreadsheets no longer support some of the old tracking fields and are reconfigured to support Caltrans latest NPDES Permit.

The SWDR Summary Spreadsheets can be downloaded from OSHDs website (http://www.dot.ca.gov/design/hsd/swdr/index.html).

The spreadsheets have hidden columns. Do not delete. Users must be careful when deleting rows from the TMT Spreadsheet that rows important to background calculations are not inadvertently deleted. Row 301 sums specific columns and transfers the data to the SWDR Spreadsheet. Lastly, do not delete any of the pre-made tabs.

#### 1.4. DATA ENTRY

Microsoft Excel software was used to develop the SWDR Summary Spreadsheets file. The file consists of two spreadsheets; the SWDR Spreadsheet (SWDR Rpt tab) tracks information related to the overall project and the Tracking Maintenance Treatment (TMT) Spreadsheet (TMT tab) tracks the individual treatment BMPs.

The Stormwater Portal tracks additional information that the SWDR Summary Spreadsheets do not. Any additional information needed to fill out the Stormwater Portal can be found in the SWDR.

The District NPDES Coordinator may enter the projects and BMPs into the Stormwater Portal or designate a staff member to enter them. See Section 5.4 of District NPDES Coordinator Handbook.

The District NPDES Coordinator is responsible for QA/QC and verifying that all the data entered for their District is accurate. See 5.5 of District NPDES Coordinator Handbook.

# 2. RESPONSIBILITIES

#### 2.1. PROJECT ENGINEER & LANDSCAPE ARCHITECT

The SWDR Spreadsheet is required to be filled out for every project phase.

The TMT Spreadsheet is only required to be filled out if there are treatment BMPs within the project with sufficient detailed design information available. If the project is in a TMDL waterbody (based on Attachment IV of Caltrans 2012 NPDES Permit), compliance units (CUs) may be claimed as early as the PID phase. A PE should consider designing treatment BMPs in the planning phases of a project only when sufficient detailed design information and supporting funds are available.

The PE or LA that signs the cover sheet of the SWDR ensures the SWDR Summary Spreadsheets data is available in the SWDR.

# 3. SWDR Spreadsheet

This spreadsheet consists of 32 columns (Figure 3-1). Each column header is identified with a number (top row), which can be cross referenced to where most of the information can be obtained in the SWDR (Figure 3-2 and 3-3). The numerical column headers have also been added to the Excel SWDR Spreadsheet tab.

1	2		3	4	5	6	7	'	3	9	10	11	12	13
SWDR Signed Date	Distric	t EA/F	Project ID	County	Route	Beg_PM	End_	PIVII	ject ription	Project Phase	Long SWDR	Risk Leve		TMDL Waterbody
14		15	16	17	18	19	)	20		21	22	2	23	24
Biofiltration Strips and Swales	Det	ention	Infiltration Devices	- LGSB	D TS	T MedF	ilter	DPPIA		SA	Other I	ВМР	Est. Const_Starl	Est. Const _Comp
25			26		27	2	28	29		30		31	32	
Net New Impervious a (NNI)		Impe	olaced ervious ce (RIS)	Treatm	litional nent Ar NTA)	ea Co Trea	ost onst tment a (ac)	Treated Imperviou Area (ad	l us :)	Treated npervious Area alance (ad	Pe Are	eated ervious ea (ac	Stabiliz	
33	34	3	35			Ţ			-		•		-	

33	34	35
MWELO	RSA	SW Comment

Figure 3-1 SWDR Spreadsheet

#### 3.1. WHERE TO FIND THE DATA IN THE SWDR

Use either the Short or Long Form Cover Sheet (Figure 3-2 & 3-3) to fill out Columns 1-12, 23-24, and 33 in the SWDR Spreadsheet (Figure 3-1). Depending on the project's potential to create stormwater impacts either a Short or Long Form SWDR is required.

See Section 2 of the SWDR to fill out Columns 13 and 34. Refer to Section 6 of the SWDR if an RSA is required.

Columns 14-22, and 28-32 are automatically filled out from the TMT Spreadsheet (Figure 4-1).

See Section 1 of the SWDR to fill out Columns 25-27.

Column 35 is used for additional comments.

APPENDIX E	10 Short Form - Storm	water Data Report
Caltrans 9	Dist-County-Route:  Post Mile Limits: 6 7  Project Type: 8  Project ID (EA): 3  Program Identification:  Phase: PID PA/ED P	S&E
Rainfall Erosivity Waiver?  3. Is the project required to 4. Does the project impact of If the answer to any of the precedence of the project impact of If the answer to any of the precedence of the project impact of Report. Unless otherwise agree  Total Disturbed Soil Area:  11	5 or more acres of soil? L or more acres of soil and not qualify for the implement Treatment BMPs? existing Treatment BMPs?  ceding questions is "Yes", prepare a Long For ed upon by the District/Regional Design Storm  New Impervious Surface: Estimated Const. Completed.	nwater Coordinator.  etion Date: 24  Not Applicable  irection of the following  contained herein and
[Stamp Required at PS&E only	[Name], Registered Project Engineer/La Architect  I have reviewed the stormwater quality this report to be complete, current, and  [Name], District/Regional Design SW Co	design issues and find accurate:
Caltrans Stormwater Qua Project Planning and Des July 2017		E-2

**Figure 3-2 Short Form Cover Sheet** 

APPENDIX E	Long Form - Stormwater Date	a Re					
	Dist-County-Route: 2 4 5						
	Post Mile Limits: 6 7						
	Type of Work: 8						
	Project ID (EA): 3						
Caltrans •	Program Identification:						
9	Phase: PID PA/ED PS&E						
Regional Water Quality Control							
Total Disturbed Soil Area: 12	2 PCTA: 28						
Alternative Compliance (acres)							
Estimated Const. Start Date:	23 Estimated Const. Completion Date:	24					
1 Risk Level: RL 1 □	RL 2 RL 3 WPCP Other:						
Is MWELO applicable? Yes	No 🗆						
Is the Project within a TMDL watershed? Yes No							
TMDL Compliance Units (acres):							
Notification of ADL reuse (if yes	s, provide date): Yes  Date:	No [					
Licensed Person attests to the	d under the direction of the following Licensed Person. The technical information contained herein and the date upons, and decisions are based. Professional Engineer or Land &E only.	n whic					
Licensed Person attests to the recommendations, conclusion Architect stamp required at PS	technical information contained herein and the date upons, and decisions are based. Professional Engineer or Land&E only.	on which					
Licensed Person attests to the recommendations, conclusions	technical information contained herein and the date upons, and decisions are based. Professional Engineer or Land&E only.	n whic					
Licensed Person attests to the recommendations, conclusions Architect stamp required at PS [Name], Registered Project Engineering Project Engineer	technical information contained herein and the date upons, and decisions are based. Professional Engineer or Land&E only.	Da					
Licensed Person attests to the recommendations, conclusions Architect stamp required at PS  [Name], Registered Project Englished Project E	technical information contained herein and the date upon an decisions are based. Professional Engineer or Landa Engineer	Da					
Licensed Person attests to the recommendations, conclusions Architect stamp required at PS  [Name], Registered Project Englished Project E	technical information contained herein and the date upon and decisions are based. Professional Engineer or Land&E only.  gineer/Landscape Architect  er quality design issues and find this report to be complete	Da					
Licensed Person attests to the recommendations, conclusions Architect stamp required at PS  [Name], Registered Project Englished Project E	technical information contained herein and the date upon an decisions are based. Professional Engineer or Landa Engineer	Da Da					
Licensed Person attests to the recommendations, conclusions Architect stamp required at PS  [Name], Registered Project Englished Project E	technical information contained herein and the date upon and decisions are based. Professional Engineer or Landa Enginee	Da Da Da					
Licensed Person attests to the recommendations, conclusions Architect stamp required at PS  [Name], Registered Project English I have reviewed the stormwater current and accurate:	technical information contained herein and the date upon and decisions are based. Professional Engineer or Landa and decisions are based and d	Da D					

Figure 3-3 Long Form Cover Sheet

#### APPENDIX E

Long Form - Stormwater Data Report

Complete the following table if treatment is required for the project.

Table E-1. Overall Project Treatment Summary Table <sup>1</sup>							
	PCTA (ac) <sup>2</sup>	Α	28				
	Treated Impervious Area (CT RW) (ac)	В	29				
	Treated Impervious Area (Outside CT RW) (ac) <sup>3</sup>	C	23			_	
	D=(	(B+C) -	A	30			

- This table is provided as an example. The table may be edited, altered, or removed as applicable or as directed by the District/Regional Design Stormwater Coordinator.
- 2 Provide treatment for ATA 1 even if NIS is less than 1 acre.
- 3 Requires Regional Board approval. Coordinate with District/Regional NPDES Coordinator.
- 4 If less than 0, additional treatment must be identified.

Figure 3-4 Overall Project Treatment Summary Table

Columns 28-30 in the SWDR Spreadsheet are automatically filled out. In Section 6 of the SWDR compare the Overall Project Treatment Summary Table (Figure 3-4) and make sure the data matches Columns 28-30 data. Verify Column 28 matches the Long Form (Figure 3-3) and the Overall Project Treatment Summary Table E-1 (Figure 3-4).

#### 3.2. COLUMN FIELD TYPES

There are four field types that data can be entered. They are date, pull down menu, number, and no restriction. There is one additional field type that data is automatically entered. The tables below include an explanation of each field. The first column is the identifier used in Figures 3-1.

If additional clarification is required while filling out fields, use the SW Comment field.

# 3.2.1. Automatically Filled in

These fields require no data to be entered. Data is automatically filled in.

**Table 3-1 Automatically Filled in Fields** 

14	Biofiltration	Biofiltration Strips and Swales
	Strips and	
	Swales	
15	Detention	Detention Basins
16	Infiltration	Infiltration Basins and Infiltration Trenches
	Devices	
17	GSRD	Gross Solids Removal Devices
18	TST	Traction Sand Traps
19	MedFilter	Media Filters

20 21 22	DPPIA SA Other BMP	Design Pollution Prevention Infiltration Areas Stabilized Areas Other BMPs  Do not fill this field out. These fields are automatically calculated using the TMT spreadsheet to determine the number of each BMP used.  Use Other BMP pull down menu for:
		o pilot and nonstandard treatment BMPs, and Caltrans approved treatment BMPs that are rarely used: Dry Weather Flow Diversion, Multi-Chamber Treatment Train (MCTT), and Wet Basin  If Other BMP pull down menu is used, insert BMP type(s) into
28	Post Const Treatment Area (ac)	the SW Comment field.  Do not fill this field out. It is automatically calculated by adding Column 25 thru 27. If PCTA is < 1 acre (5,000 sf for non-highway projects), PCTA is automatically calculated as 0 based on Permit requirements (see PPDG 4.3, Figure 4-1). If project is a non-highway project the PE must select the non-highway Route pull down menu in order for the 5,000 sf criteria to apply, otherwise the 1 acre criteria will apply.  This field is the Post Construction Treatment Area. See
29	Treated Impervious Area (ac)	Section 4.4 of the PPDG.  Do not fill this field out. This field is automatically calculated using the TMT spreadsheet. The Treated Impervious Area (ac CT R/W) column is used to sum all the TBMPs with these areas.
30	Treated Impervious Area Balance (ac)	Do not fill this field out. It is automatically calculated by subtracting Column 27 from 26.  If the project PID is signed before July 1, 2013, the following applies:  • PCTA = NNI + ATA 1, and • It is not mandatory to treat PCTA because there are no Alternative Compliance requirements.
31	Treated Pervious Area (ac)	Do not fill this field out. This field is automatically calculated using the TMT spreadsheet. The Treated Pervious Area (ac CT R/W) column is used to sum all the TBMPs with these areas.

32	Stabilized Area	Do not fill this field out. This field is automatically calculated
	(ac)	using the TMT spreadsheet. The Stabilized Area (ac) column
		is used to sum all the TBMPs with these areas.

#### 3.2.2. Date

These fields require a valid date. If you try to enter anything else, you will get an error message.

**Table 3-2 Date Fields** 

1	SWDR Signed	This is the date when the District/Regional Design Stormwater
	Date	Coordinator signs the Cover Sheet of the SWDR. The
		District/Regional Design Stormwater Coordinator is always the
		last to sign.
23	Est.	The estimated construction start date of the project.
	Const_Start	
24	Est.	The estimated construction completion date of the project.
	Const_Comp	

#### 3.2.3. Pull Down Menu

These fields have a built in pull down menu. Only valid data is entered. These pull downs are intended to help districts and project engineers enter the data correctly in a consistent format for future reference and compliance.

**Table 3-3 Pull Down Menu Fields** 

2	District	2-Digit
4	County	Caltrans County abbreviation
		If the project is in multiple counties, select Var (various) from
		the pull down menu.
5	Route	If the project is in multiple routes, select Var (various) from the
		pull down menu. If project is a non-highway project, use the
		non-highway pull down menu.
9	Project Phase	Use PID, PA/ED or PS&E.
10	LongSWDR	This is to see if the long or the short SWDR form was used;
		Yes (for long) or No (for short).
11	Risk Level	See Section 6.4.4.2 of the PPDG. Choose EW, WPCP, RL 1,
		RL 2, RL 3, or Special. Use EW for projects that are subject to
		the CGP and qualify for a Rainfall Erosivity Waiver. Use
		WPCP for projects that are exempt from the CGP and using a

		WPCP. Use Special for Tahoe Basin and tribal land. Use the "SW Comment" field when using the Special pull down (e.g., Using EPA Permit because project is on tribal lands).
13	TMDL	This field identifies if the project (or portion) is within a Total
	Waterbody	Maximum Daily Load (TMDL) waterbody based on Appendix
		D of the June 2016 SWMP. Use the SW Portal to identify if
		the project is located within a TMDL watershed based on
		Attachment IV of Caltrans 2012 NPDES Permit. Answer
		"Yes" or "No". See Section 2 of the SWDR. Refer to Section
		6.4.3 of the PPDG.
33	MWELO	This field identifies whether the Model Water Efficient
		Landscape Ordinance (MWELO) applies. Select "Yes" or
		"No". The District Landscape Architect is responsible to
		ensure the project is compliant with the Model Water Efficient
		Landscape Ordinance (MWELO) requirements included by
		California Department of Water Resources or local ordinance.
		Refer to Section 6.4.7.5 of the PPDG.
34	RSA	Does the project require a Rapid Stability Assessment (RSA)
		per Caltrans Hydromodification Requirements Guidance?
		Answer "Yes" or "No". See Section 2 of the SWDR. Refer to
		Section 6.4.3 of the PPDG.

# **3.2.4.** Number

These fields are required to be in a numeric format. Some can be decimal but some have to be whole numbers. Using less than or greater than signs or other text character will result in an error message.

**Table 3-4 Number Fields** 

12	DSA (ac)	This field can be a decimal number. If no DSA, enter 0. One decimal place to the right is available. It is recommended to use 1 at design and either 0 or 1 during planning. Use engineering judgment on significant figures to use.
		If using Common Plan of Development criteria and multiple construction locations, see your District/Regional Stormwater Coordinator how to document.
25	Net New Impervious area (NNI)	This field is the NNI. See Section 4.3 Step 7 of the PPDG. If no treatment required, enter 0 or leave blank. Two decimal places to the right are available. It is recommended to use 2 at design and 1 during planning.

26	Replaced Impervious	This field is the RIS. See Section 4.3 Step 7 of the PPDG. If no treatment required, enter 0 or leave blank. Two decimal
	Surface (RIS)	places to the right are available. It is recommended to use 2
		at design and 1 during planning.
27	Additional	This field is the ATA (Condition 1 Impervious and Condition
	Treatment Area	2). See Section 4.3 Step 7 of the PPDG. If no treatment
	(ATA)	required, enter 0 or leave blank. Two decimal places to the
		right are available. It is recommended to use 2 at design and
		1 during planning. Do not include Condition 1 Pervious.

# 3.2.5. No Restriction

**Table 3-5 No Restriction Fields** 

3	EA / Project ID	Add the 5 digit EA designation. If EAs are no longer accepted,
		use the 10 digit EFIS Project ID. This field allows numeric and
		alpha characters and must be filled out correctly. Caltrans is
		transitioning from EAs to Project IDs and this will satisfy the
		new requirement.
6	Beg_PM	If the project has only one continuous construction area (0.2
		miles or greater in length), type in the Begin post mile to match
		the Title Sheet of the plans. If the project has multiple
		construction areas, type in "Various". If the project has only
		one project location (less than 0.2 miles in length), use this field
		to report the post mile center location.
7	End_PM	If the project has only one continuous construction area, type in
		the End Post Mile to match the Title Sheet of the plans. If the
		project has multiple locations, type in "Various".
8	Project	Brief description of the project.
	Description	
35	SW Comment	Applicable comments.
		Use the following text for projects that completed the PID phase
		prior to July 1, 2013: The PID for this project was signed on
		MM/DD/YYYY, and therefore the project is grandfathered
		under the Caltrans Permit (Section E.2.d). This project is
		subject to the requirements contained within the 1999 Caltrans
		Permit.
		If the PID is signed on or after July 1, 2013 the project must
		comply with the Project Planning and Design section
		requirements of Caltrans 2012 MS4 Permit. This means
		following PCTA requirements per Section 4.4 of the PPDG. If

the project PID is signed before July 1, 2013 the following applies:

- PCTA = NNI + ATA 1,
- It is not mandatory to treat PCTA because there are no Alternative Compliance requirements.

Add text for Dry Weather Flow

# 4. TMT SPREADSHEET

This spreadsheet consists of 25 columns (Figure 4-1). Each column is identified with a number (top row), which can be cross referenced to the Column Field Types tables below. The numerical column headers have also been added to the Excel TMT tab of the spreadsheet.

1	2	3	4	5	6	7	8	9	10	11	12	13
IDNO	EA / Project ID	BMP Type	District	County	Route	LocBPM	Begin Latitude (d.d)	Begin Longitude (d.d)	LocEPM	End Latitude (d.d)	End Longitude (d.d)	Direction

14	15	16	17	18	19	20	21	22	23	24	25
Trash/Sand Capacity (cyd)	BMP Specific Comments	Treated Impervious Area (ac CT R/W)	Treated Pervious Area (ac CT R/W)	WQV Capacity (cf)	WQF Capacity (cfs)	Basis of BMP Requirement (non 402)	Stabilized Area (ac)	TMDL Waterbody	BMP Capital Cost	Water shed	RWB

Figure 4-1 TMT Spreadsheet

#### 4.1. COLUMN FIELD TYPES

There are four field types that data can be entered and explained below. They are pull down menu, number, no restriction, and currency. There is one additional field type that data is automatically entered. The tables below have three columns: column identifier, column name, and a description. The column identifier and name can be cross referenced to Figure 4-1.

Do not fill this spreadsheet out if no treatment BMPs are proposed in the project. Fill out the TMT Spreadsheet only if treatment BMP(s) are deployed.

If additional clarification is required while filling out fields, use the *BMP Specific Comments* field.

# 4.1.1. Automatically Filled in

**Table 4-1 Automatically Filled in Fields** 

1	IDNO	This is the unique BMPs identifier specific to the TMT
		Spreadsheet. Do not fill this field out. It is automatically
		filled in once the "EA / Project ID" cell is filled in on the
		SWDR Spreadsheet. See Table E-2 in PPDG. This is not the
		same IDNO that Division of Maintenance uses in IMMS.
		The SW Portal uses the IMMS naming convention.

2	EA / Project ID	<ul> <li>When existing TBMPs are to be removed or modified:</li> <li>In Section 6 of SWDR within the Treatment BMP Strategy section (see PPDG 6.4.7.3) District should provide the following tables:</li> <li>Existing TBMP Removed</li> <li>Existing BMP Modified (CDA added)</li> <li>Existing BMP Modified (CDA subtracted) and document which Caltrans NPDES Permit design requirements were used to design the BMP.</li> <li>Section 1 of the SWDR should reference these tables and add/subtract the areas to properly calculate PCTA.</li> <li>Coordinate with the District/Regional NPDES Coordinator how to document these changes in the SWDR and SW Portal.</li> </ul>
2	EA / Project ID	This field is copied from the SWDR spreadsheet.

# 4.1.2. Pull Down Menu

**Table 4-2 Pull Down Menu Fields** 

3	BMP Type	See Table 4-6 for types and brief description of each. When multiple treatment BMPs are used in a treatment train the upstream treatment BMP should be reported first followed by the next downstream treatment BMP, etc Another possible method would be to put the primary first then next, etc It is up to the district in methodology to use but should be consistent in reporting.
4	District	2-Digit
5	County	Caltrans County abbreviation (i.e., the counties in the pull down menu will be based on the District chosen)
6	Route	Use pull down menu and choose route for highway projects. If non-highway project such as a Maintenance Facility, use FAC. Leave blank for any other type. For any non-highway project use the <i>BMP Specific Comments</i> field for naming convention of non-highway facility. The PE must coordinate with the designated Maintenance Representative signing the SWDR for non-highway facility name.
13	Direction	Use the side of the roadway the BMP is located and direction traffic is headed on that side of the roadway. N, S, E, W. Use the official direction of the highway. For BMPs located on a

		connector, interchange, median, ramps or corner use the BMP
		Specific Comments field for clarification.
22	TMDL Waterbody	This field identifies if the treatment BMP is within a Total
		Maximum Daily Load (TMDL) waterbody. If the TBMP is
		not within a TMDL area, then "Non-TMDL" is selected. The
		pull down menu identifies the TMDL Waterbody (impaired
		waterbody) including the associated TMDLs (pollutants).
		Refer to Appendix D of the June 2016 SWMP. The SW
		Portal automatically identifies this information when the user
		enters a proposed BMP into the SW Portal. Use the SW
		Portal to identify the appropriate TMDL Waterbody pull
		down information.
25	RWB	Determine the Regional Water Board that the treatment BMP
		is within. It is recommended to use the SW Portal. This
		information can also be found using the WQPT
		(http://svctenvims.dot.ca.gov/wqpt/wqpt.aspx) or
		(http://www.owp.csus.edu/WQPT/wqpt.aspx).
		Division of Maintenance is required to track this field based
		on Caltrans NPDES Permit.

# **4.1.3.** Number

**Table 4-3 Number Fields** 

8	Begin Latitude (d.d)	This field is in decimal degrees. Use a minimum of 5 decimal places to the right.
		Every treatment BMP must have at least one lat. and long. BMPs easily identified in the field (e.g., basins and concrete vault structures), should have one entry at the center of the BMP. Longer BMPs or BMPs that may be difficult to locate in the future (e.g., Biofiltration Strips and Swales, DPPIA, Infiltration Trench) should identify the beginning and end.
		Use the <i>BMP Specific Comment</i> field if additional explanation is necessary. The PE and Maintenance representative should collaborate to determine best methodology to locate BMPs in the field.
9	Begin Longitude (d.d)	This field is in decimal degrees and beginning of the BMP. Use a minimum of 5 decimal places to the right. Make sure to include the negative sign.

11	End Latitude (d.d)	This field is in decimal degrees. Use a minimum of 5 decimal places to the right.
		Use the "BMP Specific Comment" field if additional explanation is necessary. The PE and Maintenance representative should collaborate to determine best methodology to locate BMPs in the field.
12	End Longitude (d.d)	This field is in decimal degrees and end of the BMP. Use a minimum of 5 decimal places to the right. Make sure to include the negative sign.
14	Trash/Sand Capacity (cyd)	Division of Maintenance is required to track capacity of a treatment BMP that collects trash or traction sand. The intent of this field is to capture the capacity of a GSRD or a TST. Use the <i>BMP Specific Comments</i> field to include specific type of GSRD or TST (e.g., Inclined Screen, Sand Vault, Loading Dock, Double Barrel, etc.). One decimal place to the right is available and recommended at all project phases. Leave field blank if treatment BMP is not a GSRD or TST.
16	Treated Impervious Area (ac CT R/W)	Use this field when designing treatment BMPs designed using WQV or WQF. Use for treated impervious area inside Caltrans right of way only. See Table E-2 in PPDG.
	N(W)	It is recommended to use 2 digits to the right of the decimal point at design and 1 or 2 during planning.
		Leave this field blank if treatment BMP is not designed using WQV or WQF.
17	Treated Pervious Area (ac CT R/W)	It is recommended to use 2 digits to the right of the decimal point at design and 1 or 2 during planning.
		Leave this field blank if treatment BMP is not designed using WQV or WQF.
18	WQV Capacity (cf)	Use this field for treatment BMPs designed using WQV. This is the design WQV treated. Input as whole number.
19	WQF Capacity (cfs)	Use this field for treatment BMPs designed using WQF. This is the design WQF treated. Use 2 decimal places to the right.
21	Stabilized Area (ac)	Two decimal places to the right are available. It is recommended to use 2 at design and 1 or 2 during planning.
		WQV/WQF field is not required to be filled out for this BMP unless calculated amount is available.

# 4.1.4. No Restriction

**Table 4-4 No Restriction Fields** 

_	1	1
7	LocBPM	Beginning post mile for the specific BMP. Use 3 decimal
		places to the right. Can be used for documenting a treatment
		BMPs location for Annual Report or can be used for paddle
		marker location.
		For areas with several treatment BMPs clumped together the
		PE and Maintenance representative may decide to fill out the
		LocBPM for the first BMP and the LocEPM of the last BMP.
		Any BMPs in between would not be filled out.
10	LocEPM	Ending post mile for the specific BMP. Use 3 decimal places
		to the right. Can be used for paddle marker location.
		For areas with several treatment BMPs clumped together the
		PE and Maintenance representative may decide to fill out the
		LocBPM for the first BMP and the LocEPM of the last BMP.
		Any BMPs in between would not be filled out.
15	BMP Specific	Any applicable comments.
	Comments	This applicable comments.
		Maintenance must have a good description of the size and
		location of the treatment BMP. Refer to Table 4-7 for
		example text.
		It is the responsibility of the PE to provide this description to
		the Maintenance Representative signing the SWDR.
		It is the responsibility of the Maintenance Representative to
		ultimately determine the final description that meets their
		needs and determine names for Maintenance Facilities.
20	Basis of BMP	This field was created to track treatment BMPs required
	Requirement	outside of the statewide NPDES Permit (e.g., 401
	(non 402)	Certification). Use the <i>BMP Specific Comments</i> field for a
		brief explanation why it was required.
24	Watershed	This field is used to track the California watershed the
		treatment BMP is within. Division of Maintenance is
		required to track this information based on Caltrans NPDES
		Permit. If the WQPT
		(http://svctenvims.dot.ca.gov/wqpt/wqpt.aspx) or
		( <u>http://www.owp.csus.edu/WQPT/wqpt.aspx</u> ) is used to
		determine the watershed, either the Calwater Watersheds
		layer or the Watershed Boundary Dataset layer can be used.

Use the hydrologic sub area (HSA) name and #. (e.g. Angels
Camp 534.22) If name is undefined then use undefined for
name (e.g. undefined 535.80). Consult with the
District/Regional NPDES Coordinator, if more guidance is
needed. The Water Quality Assessment Report (WQAR)
prepared at PA/ED, if prepared, will have this information
also.

# 4.1.5. Currency

**Table 4-5 Currency Field** 

23	BMP Capital	This field should be input as a whole number and the estimated
	Cost	cost should be rounded to Caltrans standards. This field is only
		required at the PS&E Phase. Refer to Caltrans treatment BMP
		design guidance for estimating costs captured for each
		treatment BMP.
		http://www.dot.ca.gov/hq/oppd/storm1/caltrans_20090729.html

# 4.2. BMP TYPE PULL DOWN MENU

The *BMP Type* column in the TMT Spreadsheet has the following Treatment BMPs to choose from the pull down menu. Refer to Table 4-2 in Section 4.1.2 for more information.

Table 4-6 BMP Type Pull Down Menu

BMP Type	Description
BioStrip	Biofiltration Strip
BioSwale	Biofiltration Swale
Detention	Detention Basin
Infiltration	Infiltration Basin
InfilTrench	Infiltration Trench
GSRD	Gross Solids Removal Device (GSRD)
	Use the BMP Specific Comments field to capture the type
	(e.g., Inclined Screen or Linear Radial).
TST	Traction Sand Trap

MedFilter	Media Filter include Austin Sand Filter (earthen or vault), and Delaware Sand Filter. At this time any other media filter types should use "Other BMP". If a specific media filter type is required to remove a specific pollutant of concern, use the <i>BMP Specific Comments</i> field to include an explanation. Use the <i>BMP Specific Comments</i> field to capture the type (e.g., Austin Sand Filter (earthen or vault), or Delaware.
DPPIA	Design Pollution Prevention Infiltration Area
SA	Stabilized Area
Other BMP	Use for pilot and nonstandard treatment BMPs. Insert BMP type into <i>BMP Specific Comments</i> field.  Also use "Other BMP" pull down menu for the following Caltrans approved treatment BMPs that are rarely used: Dry Weather Flow Diversion, Multi-Chamber Treatment Train (MCTT), and Wet Basin. Insert BMP type into <i>BMP Specific Comments</i> field.

# 4.3. EXAMPLE TEXT FOR BMP SIZE AND LOCATION

Maintenance must have a good description of the size and location of the treatment BMP. Example text is provided below. Refer to Table 4-4 in Section 4.1.4 for more information.

**Table 4-7 Example Text for BMP Size and Location** 

BMP Specific	Biofiltration Swale
Comments	Size:
	Trapezoidal channel with 4:1 side slopes
	L=45', W <sub>(at invert)</sub> =2', Depth of Flow <sub>(at WQF)</sub> =0.13'
	Location:
	The center of the swale is located 12 to 20 feet from Caltrans
	right of way.
	Austin Vault Sand Filter
	Size
	L=152', W=30', Height <sub>(top of slab to top of wall)</sub> =6.5-10'
	Location
	The BMP is located between Loyal Road southbound onramp
	and I-5. A maintenance pullout has been provided on the east

side of the on ramp. Use the Begin Lat/Long provided for approximate center of the BMP location.

DPPIA
Size
L=3,010', W=15-30', Height=0'
Location
The top edge is located 3' from the edge of pavement.
Use the Begin Lat/Long and End Lat/Long provided.
The first 2,500' is 15' wide then transitions to 30'. The last 500

feet is 30' wide. The transition length is 10'.

# 5. REFERENCES

Caltrans NPDES Permit ORDER 2012-0011-DWQ AS AMENDED BY ORDER WQ 014-0006-EXEC, ORDER WQ 2014-0077-DWQ, AND ORDER WQ 2015-0036-EXEC

Caltrans Project Planning and Design Guide (PPDG), July 2017, California Department of Transportation.

Final Draft District NPDES Coordinator Handbook, May 2017, California Department of Transportation.

Caltrans Treatment BMP Design Guidance (http://www.dot.ca.gov/hq/oppd/storm1/caltrans\_20090729.html)

Highway Design Manual (HDM), Current Edition, California Department of Transportation.

Stormwater Management Plan (SWMP), July 2016, California Department of Transportation.